

## V-MASSEUSE SYSTEM USER GUIDE



Thank you for choosing Valley Acrylic Products. This installation manual provides general information on the installation of our products.

All the information in this guide is based upon the most recent product information available at the time of this publication. Valley Acrylic reserves the right to make changes to product characteristics, packaging, or availability at any time without notice.

*Thank you for your purchase!*



## IMPORTANT SAFETY INSTRUCTIONS



**WARNING:** When using this unit, basic precautions should always be followed, including the following:

### READ AND FOLLOW ALL INSTRUCTIONS:

- **WARNING:** Risk of lethal electric shock. To reduce risk of electric shock, connect only to circuits protected by a Ground-Fault Circuit-Interrupter (GFCI) or Residual Current Device (RCD).
- **DANGER: To reduce the risk of injury, do not permit children to use this unit unless they are closely supervised at all times.**
- Use this unit only for its intended use as described in this manual. Do not use additional attachments not recommended by the manufacturer.
- Never drop or insert any object into any opening.
- This product is intended for indoor use only. Installing this unit outdoors could cause personal injury and will void your warranty.



**MAKE SURE THE WATER IS 1" ABOVE ALL JETS BEFORE TURNING THIS ON**  
**IF YOU TURN THE PUMP ON BEFORE THE WATER REACHES 1" ABOVE EACH JET IT CAN BURN OUT THE PUMP.**



## KEYPAD FUNCTIONS

### 1- ON/OFF - V-MASSEUSE SYSTEM

1st Press: Turn on the jets in vibration mode.  
2nd Press: Turn off the jets.

### 2- PULSATING POWER INCREASE

Press to increase power.

### 3- PULSATING POWER DECREASE

Press to decrease power.

### 4- VIBRATION SPEED INCREASE


Press to increase speed.

### 5- VIBRATION SPEED DECREASE

Press to decrease speed.

### 6- SEQUENCE MODES

1st Press: Activate sequence mode 1.  
2nd Press: Activate sequence mode 2.  
3rd Press: Activate sequence mode 3.  
4th Press: Turn off sequence mode.




## COMPONENTS

**A:** BACKLIT KEYPAD



**B:** V-MASSEUSE CONTROL BOX

**C:** V-MASSEUSE JETS

- 1- ON/OFF - V-MASSEUSE SYSTEM
- 2- PULSATING POWER INCREASE
- 3- PULSATING POWER DECREASE
- 4- VIBRATION SPEED INCREASE
- 5- VIBRATION SPEED DECREASE
- 6- SEQUENCE MODES



**A**  
BACKLIT KEYPAD



NEMA PLUG

**IMPORTANT:**  
15A/120V BREAKER WITH GROUND  
FAULT CIRCUIT INTERRUPTER CLASS "A".  
(ONE 15 AMP/120 VOLT CIRCUIT).

**THIS INSTALLATION  
COMPLIES WITH UL AND  
CSA CERTIFICATIONS  
120 VOLTS**

## VALLEY ACRYLIC LIMITED WARRANTY

### Valley Acrylic - Spa Systems:

All air blowers, pumps, electronic controls and remote controls are warranted to be free of defects in the manufacturing, material and workmanship for a period of **1 year** from the date of purchase by the initial owner/end-user.

### Exclusions Blowers:

- Chemical alteration.
- Over voltage.
- Transport or impact damage.
- Opened or modified components.
- Normal wear of the motor brushes.
- Water infiltration into the motor.

### Exclusions Pumps:

- Chemical alteration.
- Over voltage.
- Transport or impact damage.
- Opened or modified components.
- Components altered by water quality or chemical products.
- Wet-end blockage by residues. (e.g., hair).

### Exclusions Electronic controls & Remote controls:

- Chemical alteration.
- Over voltage.
- Transport or impact damage.
- Opened or modified components.



***Congratulations! You are now a part of the Valley Acrylic family, and an owner of a great product!***