







Thank you for choosing Valley Acrylic Products. This installation manual provides general information on the installation of our products.


BEFORE YOU BEGIN

- Read the instructions carefully before beginning the installation.
- Consult local building codes to make sure the installation complies with standards.
- Remove the unit from its packaging. Before disposing, packaging and taking unit from your sales person, inspect the unit to make sure it is in good shape.

• Should inspection reveal any damage or defect in the finish, Contact Us. The warranty does not cover damages or defects in the finish once the unit has been installed. Valley's responsibility for shipping damages ceases upon delivery of the product in good order to the carrier. All complaints regarding damage due to transport must be made directly to the carrier.

• It is recommended that you place the unit in the bathroom before you start. Sectional units should be disassembled if necessary. Conserve all nuts and bolts.

REQUIRED TOOLS







ASSEMBLY DRAWING



- 1. LID
- 2. SEAT
- 3. FRONT WASH NOZZLE
- 4. BOWL
- 5. REAR WASH NOZZLE
- 6. FLEXIBLE HOSE
- 7. ANGLE VALVE
- 8. ADAPTOR
- 9. CONNECTING HOSE

SPECIFICATIONS

FRONT WASH FLOW RATE	0.6 - 1.4 LPM	
REAR WASH FLOW RATE	0.6 - 1.4 LPM	
WATER SUPPLY	Water hose delivery	
WATER PRESSURE RANGE	Static pressure: 0.05-0.8 MPa	


PLEASE DO NOT DISASSEMBLE, REPAIR OR REMODEL THE PRODUCT. THE WATER SUPPLY MUST BE DRINKING WATER RATHER THAN RAIN WATER, GREY WATER OR CYCLE WATER.

website: www.valleybathandkitchen.com • E-mail: customerservice@valleyacrylic.ca • customer service call Toll Free: 1.877.398.8827 • Fax: +1.604.820.0124

BATH & KITCHEN

CSB-SC69 SOFT CLOSING SEAT BIDET


INSTALLATION GUIDE



BATH & KITCHEN

CSB-SC69

SOFT CLOSING SEAT BIDET





CSB-SC69 SOFT CLOSING SEAT BIDET

INSTALLATION GUIDE





CSB-SC69 SOFT CLOSING SEAT BIDET

MAINTENANCE

SURFACE CLEANING

Use a smooth sponge/cloth with diluted kitchen detergent to clean the product. The following things are forbidden to use for surface cleaning: hydrogen chloride detergent, paining thinner, benzene, abrasive paper, polishing agent, fragrance and insecticide, etc.




NOZZLE CLEANING

Pull out the nozzle softly and use cloth/sponge or toothbrush with kitchen detergent to clean it.



NOZZLE REPLACEMENT

- 1. Pull out the nozzle softly and hold the tube.Remove the nozzle along the arrow direction as figure A.
- 2. Hold the tube and insert the new nozzle along the arrow direction as figure B







Congratulations! You are now a part of the Valley Bath & Kitchen family.



TROUBLESHOOTING

ISSUES	CAUSE	SOLUTION
Low water flow	Water flow level is in the minimum level	Adjust water flow to the maximum level
	Low water pressure	When the water pressure is lower than 0.05MPa, please contact local department if it still doesn't work
The spray nozzle have no water	The water valve is turned off	Turn on the water valve.
	The filter screen in the flexible hose is stuck	Clean the filter screen in flexible hose
	The Nozzle is stuck	Take off the nozzle and clean it.
	The water supply pressure is too low	Increase the external water pressure
Water leaks from the bidet seat base part	The water supply pressure is too high	The maximum water pressure of this product is 0.8MPa. If water supply pressure is higher than 0.8MPa, please contact the local department for solution

Valley Bidets are warrantied for residential use for a period of 1 year from the original purchase date, against any failure from improper manufacturing defects.

website: www.valleybathandkitchen.com • E-mail: customerservice@valleyacrylic.ca • customer service call Toll Free: 1.877.398.8827 • Fax: +1.604.820.0124